



**NOTES:**

1. CASING WILL BE INSTALLED AT LINE AND GRADE SHOWN ON INDIVIDUAL PROFILE FOR EACH CROSSING. BORING/JACKING TO LINE AND GRADE IS REQUIRED.
2. TRACER WIRE SHALL BE TAPED AT 12' INTERVALS THROUGHOUT THE CASING.
3. PIPING THROUGH CASING SHALL BE RESTRAINED JOINT.
4. SEE DETAIL WS-8 FOR PIPE CASING SUPPORT DETAILS.

DETAIL:

**TYPICAL BORING & JACKING DETAIL**

SCALE: NOT TO SCALE

CFPUA DETAIL DATE:

CFPUA REV. No: 1

01/01/19



CAPE FEAR PUBLIC UTILITY AUTHORITY  
235 GOVERNMENT CENTER DRIVE  
WILMINGTON, NC 28403  
OFFICE: (910)332-6560

Stewardship. Sustainability. Service.

DETAIL NO:

**WS-7**

SHEET NO:

-